

WALL & WALL PREP SUGGESTIONS

THE WALLS

- MAKE SURE YOUR SMOOTH WALL HAS BEEN PRIMED AND PAINTED. IF IT HASN'T, WE RECOMMEND USING THE VALSPAR MULTI-SURFACE PRIMER AND ALLOW 24 HOURS TO DRY.
- IF THE WALL WAS RECENTLY PAINTED, WAIT 30-45 DAYS TO MAKE SURE THE PAINT HAS COMPLETELY OUTGASSED AND FIRST TEST FOR BUBBLES.



PROPER WALL PREP IS ALWAYS A MUST

- THE BEST METHOD OF CLEANING IS TO USE 70% ISOPROPLYL ALCOHOL & 30% WATER MIXED. CLEAN 2X WITH A LINT-FREE MICROFIBER TOWEL. WIPE IN ONLY ONE DIRECTION (NO CIRCULAR MOTIONS). THIS METHOD IS A MUST WITH LOW/NO VOC PAINTS.

**70/30
ISOPROPYL
ALCOHOL/
WATER MIX**

*ADDITIONAL CLEANING
OPTIONS FOR TOUGHER &
QUESTIONABLE WALLS:*

ROUGH SURFACE OR LIGHTLY TEXTURED?

- IF YOU FEEL THAT YOUR WALL HAS SLIGHT IMPERFECTIONS OR A LIGHT TEXTURING LIKE BRUSH MARKS, USE A 3M GOLD SANDING SPONGE AND LIGHTLY SAND THE WALL. DO NOT PRESS HARD AS IT COULD DAMAGE THE PAINT. YOU ONLY WANT TO LESSEN THE IMPERFECTIONS AND TEXTURING. AFTER SANDING USE THE 70/30 WALL PREP METHOD ABOVE.



WALL & WALL PREP

SUGGESTIONS

(CONTINUED)

NEED EXTRA SECURITY AT THE TOP OF YOUR INSTALL?

- WE OFFER PHOTO TEX ADHESIVE BOOSTER SPRAY. YOU SIMPLY SPRAY 4-6" ACROSS THE TOP OF THE INSTALL WALL AND WET APPLY.

OR

- WE ALSO SUGGEST PURCHASING 3M TAPE PRIMER AND USE THAT PRODUCT, AS DIRECTED ABOVE.

HAVE NO TIME TO WAIT?

- IF YOU ARE RUNNING OUT OF TIME AND ARE STILL CONCERNED ABOUT THE PAINT, WALLS OR SURFACE NOT BEING STABLE. OR MAYBE YOU'RE LOOKING FOR A PERMANENT SOLUTION FOR YOUR PHOTO TEX SELF-ADHESIVE FABRIC.

WE RECOMMEND USING THE ROMAN PRO 880 ADHESIVE CLEAR PRIMER. YOU WILL APPLY THIS AT THE SAME TIME AS INSTALLATION, WET. DO NOT LET THIS DRY.



DISCLAIMER: THE INFORMATION CONTAINED IS FOR SUGGESTION PURPOSES ONLY. PHOTO TEX GROUP, INC. OR ANY OF ITS AFFILIATES CANNOT BE HELD RESPONSIBLE FOR WALL DAMAGE.

FOR ANY FURTHER PREP OR PRODUCT QUESTIONS,
FEEL FREE TO REACH OUT TO:
WALTERJR@PHOTOTEXGROUP.COM